



**CHANGE TIME IN NORSTAR SYSTEM  
That has 7208 sets only**

This programming should be performed on a set that has 3 grey keys underneath the display (if you do not have one of these sets, please call for the appropriate programming template)

Programming must be done when phone in idle (no calls incoming or on hold)

The handset is to be left in the cradle while programming

**F.Y.I.: 23646 spells ADMIN on the keypad  
(this may be easier to remember)**

Press **FEATURE \* \* 23646**

Password: Enter **23646**


Press **NEXT** until it comes to time and date

Press **SHOW**

Press **CHANGE** using keypad enter the correct **HOUR**

Press **NEXT**

Press **CHANGE** using key pad enter the correct **MINUTES**

Press **Release (RLS)** 

Copy Yes
Backspace No
Change Remove
Add Default
Heading Retry
Show View
Back
Next OK

Programming Template (cut out and place beside line keys)